**Enga** Engineered air

# CenCon

# **Technical Manual**

Manual Revision 2.03









These instructions are intended as an aid to qualified, licensed installers and service personnel for proper installation, adjustment and operation of this unit. Read and understand these instructions thoroughly before attempting installation or operation. Failure to follow these instructions may result in improper installation, adjustment, service or maintenance possibly resulting in fire, electrical shock, carbon monoxide poisoning, explosion, personal injury or property damage.

© 2021 Airtex Manufacturing Partnership. All rights reserved.

www.engineeredair.com

EngA IOM67 February 2021 R201



#### INTRODUCTION

This technical manual is intended for technicians and factory personnel already familiar with the operation of Engineered Air equipment, control strategies and combustion setup.

The CenCon and expansion modules have been certified by Intertek (ETL) for use with Engineered Air appliances only, evaluated to CSA 22.2 No. 24 Temperature Indicating and Regulating Equipment and UL873 Standard for Safety Temperature Indicating and Regulating Equipment.

If any errors or omissions are noted please contact the nearest Engineered Air Technical Service Department.

To ensure warranty is honored, only qualified personnel should be employed for service or troubleshooting. If further information is required please contact the nearest Engineered Air sales office.

# Copyright

This document and the information in it are the property of Engineered Air, and may not be used or reproduced in whole or in part without written permission. Engineered Air reserves the right to revise this publication at any time, and to make changes to its content without obligation to notify any person of such revision or change.

#### **CONTACT INFORMATION**

#### Canadian Head Office and Factory

1401 Hastings Cres. SE Calgary, Alberta, Canada T2G 4C8

PH: (403) 287 2590 FX: 1 888 364 2727

Email: service@engineeredair.com

#### **USA Head Office and Factory**

32050 W. 83<sup>rd</sup> Street De Soto, Kansas, USA 66018

PH: (913) 583 3181 FX: (913) 583 1406

#### **Canadian Eastern Factory**

1175 Twinney Drive Newmarket, Ontario, Canada L3Y 5V7

PH: (905) 898 1114 FX: (905) 898 7244

# WARNINGS, CAUTIONS AND NOTICES

Warning, Caution and Notice statements are used throughout this manual to emphasize important and critical information. You must read these statements to help ensure safety and to prevent damage.

#### **⚠** WARNING:

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

#### ⚠ CAUTION:

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

## ⚠ NOTICE:

Indicates information considered important but not hazard related.

# **△** CAUTION:

If capable of heating, this appliance can discharge at high temperatures. Operate with caution as excessive heat could potentially cause damage. Fire alarms, smoke and heat detectors, sprinklers, fire dampers, etc. could activate.

Combustion setup and any service over-rides should be done with caution, and at cooler inlet temperatures. Refer to the appliance rating plate for the marked temperature rise of the appliance prior to commissioning or combustion setup.

#### **⚠** WARNING:

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operation and maintenance instructions thoroughly before installing or servicing this equipment.

# **△ △** WARNING:

This unit is connected to high voltages. Electrical shock could occur if instructions are not followed. This equipment contains moving parts that can start unexpectedly. Injury or death could occur if instructions are not followed. All work must be performed by a qualified technician. Always disconnect and lock out power before servicing. DO NOT bypass any interlock or safety switches under any circumstances.

## **△** CAUTION:

All the remote wiring must be complete and functional before attempting to start the appliance.

## **△** CAUTION:

It is important that the service technician understands the CenCon is a configurable controller. Its operation on one appliance of equipment may not mimic another.

# **⚠** CAUTION:

The CenCon is specifically programmed for this specific appliance. Do not replace with another controller without confirming its program suitability with Engineered Air.

# TABLE OF CONTENTS


GENERAL OVERVIEW 6
HARDWARE INFORMATION 6
COMPUTER CONNECTION
INTERFACE SCREENS
KEYPAD8
DISPLAY SCREENS
HOME SCREEN 9
HEATING 9
COOLING9
ECONOMIZER 9
CENCON ANALOG I/O10
CENCON DIGITAL I/O10
HEATING ANALOG I/O10
HEATING DIGITAL I/O10
COMMUNICATION
SETTINGS11
ALARMS11
TERMINAL DESCRIPTION
OPERATION13
MODE SELECTION
OCCUPIED / UNOCCUPIED13
FAN CONTROL
VARIABLE AIR VOLUME13
AIR PROVING SWITCH13
WARMUP/COOLDOWN14
DAMPER CONTROL14
MAKE UP AIR14
DAMPER END SWITCH14
AMBIENT COMPENSATION14
ECONOMIZER15
DIFFERENTIAL ENTHALPY ECONOMIZER 15
MINIMUM POSITION 15
CALIFORNIA BUILDING ENERGY EFFICIENCY -
TITLE 24 15

HIGH AMBIENT LOCKOUT	15
DAMPER CONTROL BY OTHERS	16
LOW LIMIT	16
HEATING	16
GAS FIRED HEATING	16
COOLING	16
ENERGEY RECOVERY	17
GENERAL TIMING	17
TEMPERATURE CONTROL	17
ROOM OR RETURN THERMOSTAT	17
REMOTE SETPOINT	17
BMS SETPOINT	17
ALARM DESCRIPTION	18
ALARM RESET	18
WIRING CONCERNS	18
MODULE GROUNDING	18
COMMUNICATION WIRING	19
COMMUNICATION WIRE GROUNDING	20
EXPANSION MODULES (XM)	21
J-XM	22
BASIC OPERATION	22
TERMINAL DESCRIPTION	23
J-XM / CD-XM TIMING	24
J-XM COMBUSTION SETUP	25
GAS ACTUATOR CALIBRATION	25
COMBUSTION OFFSETS	25
ALARM DESCRIPTION	27
G-XM	28
BASIC OPERATION	28
G-XM TIMING	29
TERMINAL DESCRIPTION	29
G-XM COMBUSTION SETUP	30
GAS AND AIR ACTUATOR CALIBRATION	30
COMBUSTION OFFSETS	30
ALARM DESCRIPTION	32
M-XM	22

# $egin{align*} \mathbf{EngA} \ \mathbf{Engineered} \ \mathsf{Air} \ \end{bmatrix}$

BASIC OPERATION	CD-XM	49
M-XM / P-XM TIMING	BASIC OPERATION	49
TERMINAL DESCRIPTION	P-XM	50
M-XM BURNER SETUP35	BASIC OPERATION	50
MAXITROL VALVE35	Appendix A - Thermistor Output Table	52
GAS ACTUATOR CALIBRATION	Appendix B - Maxitrol Valve Adjustments	53
ALARM DESCRIPTION36	Appendix C - Startup Checks	54
Profile Pressure Setpoint	Appendix D - Service Issues	54
C-XM	CenCon Specific	54
BASIC OPERATION	READ AND SAVE FEATURES	54
C-XM TIMING	COMMUNICATION ALARM	54
TERMINAL DESCRIPTION39	ERRATIC BEHAVIOR	54
STAGED COMPRESSORS	HARD RESET BUTTON	54
AMBIENT CONDENSER FANS	Miscellaneous	55
LOW AMBIENT LOCKOUT40	COMBUSTION ANALYSIS	55
CONDENSER REHEAT	POOR PILOT SENSING	55
H-XM41	REGULATOR RESPONSE	55
BASIC OPERATION	WATER AND ICE FROM COMBUSTION	55
TERMINAL DESCRIPTION	MANIFOLD PRESSURE	55
HIGH AMBIENT LOCKOUT	CUSTOMER INSTALLED SENSORS	55
S-XM	SPEED SENSOR - DJ	56
BASIC OPERATION	TOP LOADING	56
S-XM TIMING	AIR BALANCING	56
OPERATION NOTES	Appendix E - BACnet / Modbus	57
TERMINAL DESCRIPTION	Wiring	57
S-XM BURNER SETUP45	RS485	57
ALARM DESCRIPTION45	Ethernet	57
ER-XM	Appendix F - DJ/DG Fuel Curve Development .	58
BASIC OPERATION	Combustion Record - DJ and Large SH/SHX .	59
TERMINAL DESCRIPTION	Combustion Record - DG	60
ALARM DESCRIPTION	Combustion Record - HE	61
YP-YM 48	Combustion Record - Small SH/SHX	62

#### **GENERAL OVERVIEW**



The Engineered Air CenCon controller is the primary operational component for the majority of custom manufactured Engineered Air HVAC equipment. Expansion modules (-XM) may be added to extend the operational capabilities to gas fired heating, cooling, humidification and energy recovery systems.

# ⚠ Notice:

There is approximately a 1 minute delay before operation can commence on initial power up. The CenCon has to load parameters and configurations prior to operation. The time varies depending on the complexity of the equipment it is controlling.

#### HARDWARE INFORMATION

Control Voltage	24Vac 60Hz
Digital Output Rating	120V 10A
Digital Input	24 - 120Vac¹
Analog Output	0-10Vdc
Analog Input	0-10Vdc and 4-20mA <sup>2,3</sup>
Analog In Impedance	7.5kΩ
Temperature Rating	-40 - 150°F (65°C)
Temperature Sensor	10k Type 2 NTC

#### **Apparent Power Ratings**

CenCon	10 VA
J-XM, G-XM, M-XM, S-XM, ER-XM	30 VA
C-XM	20 VA
XP-XM	12 VA
CD-XM	5 VA
P-XM	5 VA

<sup>&</sup>lt;sup>1</sup> Digital input connection to the CenCon or any of the expansion modules cannot use Mosfet solid state switches. Input switching must be mechanical.

 $<sup>^2</sup>$  If using 4-20mA, add a 500 $\Omega$  resistor across the input terminals.


<sup>&</sup>lt;sup>3</sup> Analog inputs will trigger 10Vdc 'high' if using 24Vac input and a series Diode (1N400x).

#### COMPUTER CONNECTION

Direct connection may be made to a Windows 10 OS computer or tablet. To gain access to the CenCon testing interface connect using a Cat.5 Ethernet cable to the CenCon, near the top right of the controller. Tablets may require a USB to Ethernet adapter. Any Windows based web browser should work.

To set the correct IP address, click the Start button, then Settings, then Network and Internet. Then, click Ethernet (on the left side), then Change Adapter Options. Click the Ethernet icon and a status page should open. Press Properties, then Ethernet, then select Internet Protocol Version, and then Properties.

Set a static IP address on the computer with the following settings:



Click OK to accept, and then open a web browser and type in the following address to gain access to the testing interface:


# 192.168.0.10:8080/webvisu.htm

To simplify connections, make this a bookmark in the web browser for future connections.

#### INTERFACE SCREENS


The layout of the display screen depends on the age and version of the CenCon.

The third release screens have been improved for visibility and tablet use. Note the tabs along the top for more screens. The background is black. This image is grey for printing purposes.



#### **KEYPAD**

The 9 button keypad has been configured to easily manipulate any user variables available for modification. Typically, this would include the temperature setpoint(s) and outside air minimum position.





The home button displays the main page.



Pressing the alarm button changes the display to the alarm page.



The left and right double arrow keys increment the display to the next page.



Use the left and right arrows to navigate the location of the cursor within each page.



Press the enter key once the cursor is located at the variable to be changed.



The up and down arrows change the value of the indicated variable.\*

\*Changing a variable is 'live'. Pressing enter is not required to set the value.

#### **DISPLAY SCREENS**

The CenCon display can show a variety of the input and output conditions, in addition to the current operating variables. Additional screens become available as expansion modules (-XM) are added to the system. The display screen saver will automatically go blank after 5 minutes. Pressing any key will reactivate the screen and return to the home page.

#### **HOME SCREEN**

The Home screen  $\widehat{\Box}$  displays the required setpoint, actual discharge temperature, and various active modes of operation.

HOME	
Setpoint 70°F	Discharge 70.3°F
Unit ON	Mode HEATING
Damper ON	Blower ON
Alarm Display	

Pressing the right page advance  $\gg$  changes the display to the next status page(s). Note the top right corner describes which module the variables relate to. The sample list that follows may or may not be present in the particular appliance using the CenCon.

#### **HEATING**

G-XM sample shown, heating enabled, with the main valve enabled.

HEATING	G-XA	٨
Setpoint 90 °F	Discharge 89.3 °F	
Demand 16.9 %	Aux. Heat 0.0 %	
Burner Sequence	1234667	

#### **COOLING**

Showing stages 1 to 3 enabled, out of 6 total.

COOLING		C-XM
Setpoint 55 °F	Discharge 57.1 °F	
Setpoint 55 °F Demand 16.9 %	Aux. Cool 0.0 %	
Compressors	000456	

#### **Burner sequence**

- ① Move to purge
- 2 Purge
- 3 Move to ignition
- ④ Ignition / pilot
- 6 Main valve
- 6 Post purge
- Shutdown

#### **Compressor Stages**

- Stage #1 On
- 2 Stage #2 On
- Stage #3 On
- 4 Stage #4 Off
- ⑤ Stage #5 Off
- 6 Stage #6 Off

#### **ECONOMIZER**

ECONOMIZER			CENCON
Mixed Air	59.3 °F	Discharge	53.8 °F
Ambient Air	72.5 °F	Return Air	75.8 °F
Min. Position	20.0 %	Damper	34.5 %

# **CENCON ANALOG I/O**

ANALOG I/O					CENCON
MEc	7.2 V	MHW	0.0 V	MCW	0.0 V
MSp	0.0 V	IAQ	0.0 V	RPM	0.0 V
HuO	0.0 V	HR +/-	0.0 V	FbD	0.0 V
ASP	0.0 V	W +/-	0.0 V	Y +/-	0.0 V

# CENCON DIGITAL I/O

DIGITA	L I/O				CENCON
SA		DM	$\overline{\checkmark}$	AL	
OLF		FbB		DES	
FS	$\overline{\checkmark}$	OCC			
BAL		DhC			

# **HEATING ANALOG I/O**

ANAL	.0G I/O			G-XM
MBV	4.41 V	CP	24.4 kΩ	
FbG	4.39 V			
MCA	3.74 V			
FbA	3.71 V			

# **HEATING DIGITAL I/O**

Ī	DIGITA	G-XM			
	EnH	SR	$\overline{\checkmark}$	CAS	
	FbV	FR	$\overline{\checkmark}$		
	HL	PV			
	BFS	СВ	$\overline{\mathbf{A}}$		

#### **COMMUNICATION**



Enga ENGINEERED AIR

COMMUNICATION

EMS Enabled: (YES/NO)
Protocol: (IP / MSTP / NONE)
External MSTP Baud Rate: 38,400
Setpoint Location: (KEYPAD / EMS)

#### **SETTINGS**

SETTINGS

Load From FactoryNoLoad From Default UserNoSave to Default UserNo

#### **ALARMS**

ALARMS

Unit: No alarms Reset NO

Heating: No alarms Cooling: No alarms

Communication: No alarms

# **TERMINAL DESCRIPTION**

Terminal	Туре	Name	Description	Value
HN		Power Supply		24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal network	
BmA,B		BACnet	BACnet network slave (Future)	
SmA,B		Modbus	Modbus network slave (Future)	
MCW	AO	Modulating cooling	Chilled water coil valve actuator. 0V=off.	0-10 Vdc
MEc	AO	Modulating economizer	Economizer / Mix box actuator. OV=closed.	0-10 Vdc
MHW	AO	Modulating heating	Hot water coil valve actuator. 0V=off.	0-10 Vdc
MSp	AO	VFD command speed	VFD control signal.	0-10 Vdc
RPM	Al	VFD feedback speed	Confirmation of VFD speed.	0-10 Vdc
DPr	Al	Supply duct pressure	Duct pressure sensor signal.	0-10 Vdc
HuO	Al	Outside humidity	Outside / ambient air humidity sensor.	0-10 Vdc
CM		Relay common	Common power to output relays.	24 Vac
FbD	Al	Damper feedback	Damper actuator position feedback signal.	0-10 Vdc
OLF	DI	VFD fault	Motor overload or VFD fault input.	24 Vac
FbB	DI	Air proving switch	Supply blower air proving switch.	24 Vac
DES	DI	Damper end switch	Mechanical damper end switch.	24 Vac
AL	DO	Alarm	Alarm contact for annunciation.	24 Vac
SA	DO	Supply air	Blower enable contact.	24 Vac
DM	DO	Damper actuator enable	Two position actuator control.	24 Vac
OCC	DI	Occupied / Unoccupied	Enable occupied mode when powered.	24 Vac
TCB	DI	Time clock bypass	Momentary push button (future)	24 Vac
EnF	DI	Enable Fan	Occupied mode start	24 Vac
ALi	DI	Secondary Bacnet alarm	Spare alarm input for BACnet annunciation.	24 Vac
Y+-	Al	Modulating cooling thermostat	Independent cooling demand signal.	0-10 Vdc
MA1,2	Al	Mixed air temperature	10k Type 2 thermistor	Ohms (Ω)
DA1,2	Al	Discharge temperature	10k Type 2 thermistor	Ohms (Ω)
AA1,2	Al	Ambient air temperature	10k Type 2 thermistor	Ohms (Ω)
RA1,2	Al	Return / room temperature	10k Type 2 thermistor	Ohms (Ω)
W+-	Al	Modulating heating thermostat	Independent heating demand signal.	0-10 Vdc
ASP	Al	Remote VFD setpoint	VFD speed input demand signal.	0-10 Vdc
Hr+-	Al	Modulating humidity	Independent humidity demand signal.	0-10 Vdc
DX1,2	Al	DX temperature	10k Type 2 thermistor	Ohms (Ω)
DhC	DI	Dehumidification.	Dehumidification call input.	24 Vac
Вур	DI	VFD Bypass	VFD bypass input.	24 Vac
RmA,B		Modbus Room	Modbus room thermostat (Future)	

#### **OPERATION**

#### **MODE SELECTION**

The CenCon can operate under up to 4 distinct modes; heating, economizer, ventilation and cooling, in addition to combinations. There is a delay between changing from one mode to another in order to prevent cycling of the equipment. Mode selection is determined by the demand call and the ambient temperature. The CenCon must have an ambient sensor installed either within the appliance, or remotely located to measure the ambient temperature.

#### **OCCUPIED / UNOCCUPIED**

During night, or unoccupied, operation, when the modulating room thermostat is calling for more than 60% heating demand, the heater will operate at the maximum discharge setpoint of 120°F until the room thermostat demand falls below 20%.

#### **FAN CONTROL**

#### **VARIABLE AIR VOLUME**

On a blower start signal, and before the blower is started, the VFD feedback signal is checked for a false signal. If a false feedback signal is detected the unit will go into alarm and not start. If the signal remains above the trip set point for 30 seconds, the SA flow alarm is set. After the blower is started, the feedback signal must rise above the low flow trip point. If it does not, after 30 seconds the SA flow alarm is set and the equipment shuts down.

Compressors, electric heat or direct fired burners are not allowed to run until the air flow is above minimum feedback. While the blower is normally operating and the feedback drops 5% below the low air flow set point, a low air flow warning is displayed and the 15 second alarm timer is started. If the air flow rises above the low flow set point within 15 seconds, the low flow timer resets and the unit reverts to normal operation. During this 15 sec time delay, compressors and heat exchanger style burners are allowed to stay running.

VFD minimum speed should not be set to 0%. The design minimum is 35%, or 3.5Vdc. Confirm with the unit function what the specific design minimum is. The feedback signal should not be scaled, and must send a 3.5 to 10.0Vdc signal to the CenCon. Confirm the feedback signal generates a full signal range to the CenCon. Adjust the output range to compensate if unable to meet 10.0Vdc minimum. The feedback output on the ACH-580 drive is typically set to 10.6Vdc at maximum to ensure 10.0Vdc at the CenCon. Confirm the feedback display reads 100% on the computer or the keypad display.

#### **AIR PROVING SWITCH**

On a blower start signal the air proving switch must be in the open position. If a closed position is detected, the fan is not allowed to start and a 30 second alarm timer is initiated. The alarm will automatically clear if the switch opens within 30 seconds.

If the flow proving switch is open, the blower can start normally. After the blower starts, the CenCon needs to see the air switch close (prove) within 30 seconds. If the switch does not close, the low air flow alarm is triggered. If during normal operation, the flow proving opens, a 15 second low air flow lock out timer is started. During this time, compressors and heat exchanger style burners are allowed to stay running. Once the 15 second timer has elapsed, the equipment will shut down on low air flow alarm.

#### WARMUP/COOLDOWN

A blower warmup/cooldown delay may be required to preheat or cool down the heat exchanger. For DG and DJ style heat exchangers a full heat exchanger warm up delay is required when the ambient temperature is below the low limit set point or when the ambient temperature is 8°F or more colder than the discharge set point but above the full warmup required ambient.

The base blower delay off time is automatically set according to the application and type of heating device, according to the table below.

Application	* Damper delay	Exchanger Warm up delay	Cool down delay
MUA	On 90 sec Off 20 sec	DJ: 75 sec DG/DJX: 75 sec Other: 0 sec	DJ: 90 sec DG: 90 sec DJX: 90 sec
Mixbox	On 10 sec Off 10 sec	DJ: 75 sec DG: 75 sec Other: 0 sec	HE: 8 sec Other: 30 sec

<sup>\*</sup>The damper off delay starts when the blower is shut off

#### **DAMPER CONTROL**

#### **MAKE UP AIR**

Make up air equipment will normally use a 2 position actuator to open or close the inlet dampers.

#### **DAMPER END SWITCH**

A damper end switch is a mechanical device used to prove the dampers have opened. The switch may be independent, or an auxiliary contact from the damper actuator. If used, when the damper end switch 'makes' and inputs 24Vac to terminal DES, the fan delay timer truncates to zero, and the fan will start.

#### **AMBIENT COMPENSATION**

On blow through heat exchangers, the blower sees greatly varying inlet temperatures. As the air temperature changes, so does the air density and volume. The blower delivers a constant volume of 'cold' air. As this air is warmed by the heat exchanger, it expands causing the outlet air volume to increase. With the extra air volume, the temperature rise falls and there may not be enough heat on a design day.

The ambient compensation attempts to correct this by partially closing the inlet damper enough to add enough system static to compensate for the expansion effect. The compensation starts to reduce the damper opening at 30°F and reaches maximum effect at -40°F. The low limit operation has no effect on the ambient compensation package. This option requires a modulating damper actuator and opposed blade dampers.

#### **ECONOMIZER**

Economizer damper control will mix the return and outside air streams to achieve the required discharge air temperature. The CenCon may also be configured to employ an additional mixed air sensor downstream of the mixing dampers.

It is possible for the economizer to operate while in heating or cooling mode. While the display will show either heating of cooling, the analog output to the economizer will be active and show a value greater than the minimum position.

Applications may require economizer damper control 'by others'. This requires the CenCon to be programmed as a MUA, and uses the FbD (Outside Air Feedback Damper) input to allow the CenCon to adjust and reset the low limit bypass timer if required during a significant increase in cold outside air.

#### DIFFERENTIAL ENTHALPY ECONOMIZER

Differential economizer damper control calculates the outside air enthalpy and compares it to the return air enthalpy. If the outside air calculation is less than the return air calculation the damper control will mix the return and outside air streams to achieve the required discharge air temperature. If the outside air calculation is greater than the return air calculation, the dampers will revert to minimum position. The CenCon may also be configured to employ an additional mixed air sensor downstream of the mixing dampers.

#### MINIMUM POSITION

The minimum position setting is preset by design to the setting noted by sales, and may be adjusted using the display keypad, a computer interface, Modbus or BACnet. The IAQ terminal can be used to reset the damper minimum position by supplying a 0-10vdc signal which corresponds to 0-100% position of the damper. If this input is less than the minimum position setting in the controller, that setting will be used. This setting corresponds to the actuator output signal, not the actual air volume.

#### CALIFORNIA BUILDING ENERGY EFFICIENCY - TITLE 24

This standard dictates that the economizer must be monitored and prove the mechanical operation of the dampers. This is achieved by a number of methods. Whenever the economizer is in the full open position, a damper end switch is activated to indicate that the dampers are operating correctly. A mixed air sensor must be installed to give feedback on the effectiveness of the mixing section and to act as a mixed air low limit.

#### HIGH AMBIENT LOCKOUT

This feature is required in order to disable the economizer if there is no cooling available from the ambient air.

This can be performed by two different methods. Differential temperature is generally the method used and compares the ambient temperature to the return temperature. A second method is differential enthalpy. Humidity sensors are installed in the return and outside air, and enthalpy is calculated based on the humidity and temperature readings.

#### DAMPER CONTROL BY OTHERS

The CenCon will enable power to the dampers when the unit is enabled and requested to run. The dampers will then be controlled from a signal by others with a field installed mixed air sensor. The minimum position must be set by others (CenCon does not have damper override).

#### **LOW LIMIT**

Based on discharge air temperature sensing, the low limit will disable unit operation if the temperature falls below 40°F (4°C). The setpoint is not adjustable. Low limit, or freeze protection, may be enabled or disabled. The low limit bypass has 2 timers, the main bypass timer that occurs at initial startup of the supply fan, and an anti-nuisance timer. The anti-nuisance timer has a duration of 30 seconds and resets once the discharge temperature rises above the low limit setpoint. The main bypass time is 4 minutes for all types of equipment.

On variable air volume systems the main low limit bypass time is reset if the economizer minimum position is suddenly increased by over 15%, or if the VFD speed increases by over 20%, both within 10 seconds.

The bypass time is reduced to 2 minutes if the heating has been disabled. The low limit is not active in cooling mode.

#### **HEATING**

The CenCon may control simple fluid based heating devices from the auxiliary heating 0-10Vdc output. Expansion modules are necessary for gas fired heating to monitor and control the increased complexity and safety requirements of gas fired equipment.

The MHW (Modulating Hot Water) output is a 0-10Vdc signal, with 0V=no heat and 10V=max heat, typically associated with a hot water coil. Reversing function must be done at the actuator. A spring return actuator would be required for applications desiring full open, closed or bypassed when the equipment is off.

#### **GAS FIRED HEATING**

Commands to heating expansion modules are done via the internal Modbus network. Refer to the appropriate expansion module section for more information.

#### COOLING

The CenCon may control simple fluid based cooling devices (chilled water or glycol) from the auxiliary cooling 0-10Vdc output. Expansion module(s) for mechanical cooling are necessary for staged or modulating mechanical cooling. Refer to the C-XM cooling expansion module section.

The MCW (Modulating Chilled Water) output is a 0-10Vdc signal, with 0V=no cool and 10V=max cool, typically associated with a chilled water coil. Reversing function must be done at the actuator. A spring return actuator would be required for applications desiring full open, closed, or bypassed when the equipment is off.

#### **ENERGEY RECOVERY**

The CenCon will try to maximize the energy recovery portion of the unit before providing additional heating. When demand on the ER-XM achieves 100%, the additional heating device (if present) will be activated to provide supplemental heat to achieve the discharge air setpoint.

#### **GENERAL TIMING**

Mode Change time	1 minute	
Damper delay off	20 seconds	
Supply low airflow alarm	30 seconds	
Shorted Damper End Switch	1 second	
Supply air shorted air switch alarm	30 seconds	
Low limit bypass	4 minutes + 30 second anti-nuisance	

#### **TEMPERATURE CONTROL**

The CenCon is a discharge air temperature controller. The discharge setpoint is adjusted from the CenCon display and keypad, between maximum and minimum limits determined by design.

There are a number of methods to change, or 'reset' the discharge temperature to what the space requires.

#### **ROOM OR RETURN THERMOSTAT**

The thermostat will have independent 0-10Vdc outputs for heating, cooling, or both.

The selected room thermostat is the Viconics VT7200F5000. This thermostat has (2) distinct 0-10Vdc analog outputs, for heating (W+/-) and cooling (Y+/-). Refer to the field wiring diagram included with the appliance for wiring connections.

A remote wall sensor (S3010W1000) is available for various single or averaging room sensor arrangements. Further information can be found at <a href="https://www.viconics.com">www.viconics.com</a>.

#### Mounting locations:

- Do not install on an exterior wall.
- Do not install near any heat source.
- Should not be installed near an air discharge opening.
- Should not be affected by direct sunlight.
- Must be open to air circulation around the thermostat.

#### **REMOTE SETPOINT**

A Belimo SGF24 (0-10Vdc) with a calibrated temperature dial may be used to directly change the discharge temperature (W+/-).

#### **BMS SETPOINT**

This method uses a single 0-10Vdc input (W+/-) to modify the discharge temperature between the upper and lower maximum temperature values.

#### ALARM DESCRIPTION

The last alarm event will be shown on the main page of the CenCon display. A more detailed list can be found by pressing the alarm keypad button  $\triangle$ . Additional alarms specific to the system are detailed by expansion module type.

Low limit	The low limit setpoint is the lower of 40°F or 15°F below the discharge air
	setpoint.
Air Proving Fault	VFD Feedback is greater than the minimum VFD speed for more than 30
All 110Villg Laute	seconds with the supply fan output off.
Shorted Air Proving	Air Proving switch shorted on startup.
Low airflow	Air Proving switch opens during operation for 30 seconds or the VFD
Low airrow	feedback drops below the minimum speed for 30 seconds.
Discharge Air Sensor Failure	Discharge Air sensor is outside of its range (-60°F to 220°F) for 10 seconds
Discharge All Sensor Fallure	or more.
Ambient Air Sensor Failure	Outdoor Ambient sensor is outside of range (-60°F to 220°F) for 10
Ambient An Sensor Faiture	seconds or more.
Damper End Switch Warning	Shorted damper end switch. Meaning the damper end switch is made
Damper Life Switch Warning	before energizing the damper output.
Damper Mechanical Alarm	End switch enabled codex is true and end switch is not made after
Damper Mechanical Alarm	energizing damper output.
Communication Error	Triggered on loss of communication with application modules.

#### **ALARM RESET**

To reset from the computer screen, press the Alarm Reset button on the main screen. To reset from the CenCon keypad, press the  $\triangle$  button, then  $\leftarrow$  to move the cursor to the reset area. Then press  $\blacktriangle$ .


#### WIRING CONCERNS

For purposes of unit wiring to chassis in this manual, grounding and bonding reference the same thing and may be used interchangeably. Shielded cables always include a ground connection wire, uninsulated, called a 'drain' wire.

#### **MODULE GROUNDING**

The CenCon and all expansion modules have a black power connection termination that includes Hot (H), Neutral (N), and Ground (GND). The GND terminal must be connected to a short green wire securely fastened to unpainted metal directly below the termination of each and every expansion module.

As shown in the example below, the DJ speed sensor wire shield drain wire must connect to the same unpainted ground connection used by the CD-XM input power. The communication wire ground should only connect to the CenCon unpainted ground connection.



#### **COMMUNICATION WIRING**

#### **⚠** NOTICE:


Correctly wiring the internal Modbus communication network is critical to ensuring stable operation. Maintain the wiring at least 6" (150mm) away from any high power wiring, motors, transformers or VFD's.

The CenCon communicates with expansion modules via an internal Modbus communication protocol. The (pink jacket) wire is specific for Modbus communication: ASTM B33, Twisted pair, 22ga. fully shielded with drain wire, and plenum rated jacket. An end of line resistor (EOL termination) should not be required due to the relatively short length of the internal Modbus wiring. Care must be taken to ensure correct polarity between modules.

**⚠** NOTICE:


For consistency, always wire: Red to LmA Black to LmB.

Starting at the CenCon, wiring must be routed in series, or 'daisy chained' as shown below. There should never be more than 2 communication wires at any LmA/LmB terminal.










#### **COMMUNICATION WIRE GROUNDING**

The communication wire drain should be connected only at the same unpainted ground termination used by the CenCon panel ground. All expansion module intermediate drain wires must be twisted together tightly and taped to secure together and isolate from ground. A wire nut or insulated splice connector may also be used. It is important that these must not be grounded anywhere except at the CenCon ground connection.



# **EXPANSION MODULES (XM)**


The CenCon controller can be connected to any Engineered Air expansion module. The expansion module provides the required wiring terminals for each additional appliance it is controlling.

All expansion modules have (2) lights. The Green light is indication of power, and the blinking yellow light is to show communication to the CenCon is connected.

Expansion Module	Engineered Air Appliance Type
J-XM	DJ (S, E, X) style indirect fired heating up to size 140.
G-XM	DG, and DJX indirect fired gas burners, sizes 200 and 300.
M-XM	HE direct fired gas heating.
H-XM K binary staged electric heating.	
C-XM FW, CU, UPW staged mechanical cooling.	
ER-XM Energy recovery Wheel, Pipe and Plate style energy recovery systems.	
S-XM SH and SHX gas fired humidification.	
XP-XM	Additional BACnet parameters module.
CD-XM In addition to J-XM for DJ (E, S, X) burners up to size 140, and SH(X) sizes 12	
P-XM	Static pressure sending, in addition to M-XM for profile pressure sensing module on direct fired burners.

# J-XM

For indirect fired equipment with DJ (E, S, X) style burners up to size 140.



#### **BASIC OPERATION**

On a call for heating the combustion blower will be enabled to full speed to prepurge the heat exchanger. Once the prepurge time has elapsed the combustion blower speed will reduce to ignition speed and then enable the ignition control to start and prove pilot flame, then open the main safety valve (SSOV). After a time delay the J-XM will disable the pilot valve. The burner is allowed to operate to maintain the requested discharge air temperature from the CenCon by modulating the control valve and the combustion blower speed. If heating is not required the burner will be disabled and the combustion blower will enter a post purge time, and then shut down.

The J-XM burner expansion module can control either a Maxitrol magnetic style modulating valve or an actuator and ball valve.

Combustion air blower modulation is controlled by either the CD-XM expansion module. If using an electronically commutated motor (ECM) modulation is directly controlled from the J-XM.

# **TERMINAL DESCRIPTION**

Terminal	Type	Name	Description	Value
HN		Power Supply		24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
FbG	Al	Feedback Gas	Compares the ball valve actuator feedback signal to the demand signal.	0-10 Vdc
MBV	AO	Modulating ball valve	Modulating gas valve actuator output.	0-10 Vdc
CAS	DI	Combustion air switch	Optional proof of combustion air flow.	24 Vac
BFS	DI	Blocked flue switch	Normally closed, opens on blocked flue.	24 Vac
EnH	DI	Enable heat	24V must be applied to allow heating function.	24 Vac
PV1, PV2	DO	Pilot valve	Disables the pilot flame once the main burner has been established.	24/120 Vac
SR1, SR2	DO	Safety relay	Secondary safety lockout contacts	24/120 Vac
FR1, FR2	DO	Flame relay	Flame relay enable contacts.	24/120 Vac
FbV	DI	Feedback valve	Feedback signal from the safety shut off valve (SSOV). Wired directly to valve.	24/120 Vac
VN		Valve neutral	Neutral feedback signal from the safety shut off valve (SSOV).	
HL	DI	High limit	Normally closed, opens on high temperature.	24 Vac
СР	Al	Condensate probe	Condensate probe sensor input.	Ohms (Ω)
MX1, MX2	AO	Maxitrol Valve	DC current output to the Maxitrol modulating valve.	mAdc
ECO	AO	ECM Demand	Electronically Commutated burner motor control output signal.	0-10 Vdc
PWM	PWM	ECM rpm feedback	Pulse width modulation feedback signal from Electronically Commutated burner motor.	PWM
ECC		ECM Neutral	Neutral reference to ECO output signal.	

# J-XM / CD-XM TIMING

Prepurge	60 seconds
Post purge	5 minutes
Flame failure	15 seconds lockout on ignition control and 60 seconds on burner
Pilot opening time	8 seconds
Open combustion air proving	30 seconds
RPM out of range	60 seconds
Improper gas valve wiring	2 seconds
Blocked condensate	5 minutes
Blocked flue	10 seconds trip and 1 minute to alarm
Heat exchanger cool down	90 seconds if the discharge air is above 50° (10°C), else none.
Heat exchanger warm up	75 seconds if ambient air is less than 40°F (4°C) and discharge temperature less
fan delay	than 90°F (32°C), else no warm up.
Burner cool down	90 seconds if the burner has been on for more than 30 seconds, else no burner cool down

#### J-XM COMBUSTION SETUP

Combustion setup may only be done using a computer.

#### **⚠** NOTICE:

Always allow the heat exchanger temperatures to stabilize before accepting combustion values.

A full set of clocking data must be completed in factory test bay to generate a data base of combustion fuel curves.

#### GAS ACTUATOR CALIBRATION

# **⚠** WARNING:

If using a ball valve and actuator for gas, it must be pre-calibrated before attempting to set combustion offsets. This is normally completed at initial factory setup, but will also need to be verified if the actuator is replaced.

For field serviced, record all offset values, and then set all values to zero. Enter calibration screen and perform calibration setup. Return and re-set offset values.

#### ⚠ WARNING:

Before performing the calibration procedure, turn Off the appliance gas supply.

Power the CenCon, leave the heat switch and fan switch off. Turn off the gas supply to the appliance.

Press the **UP** arrow to enter the Actuator Calibration Screen.

Press: Start Setup, then Closed (0%)

The fuel actuator will move to fully closed (90°) position, and read 2V. Set the ball valve to fully closed mechanically, and tighten linkage. The feedback must be at or very near 2V. Enter the actual feedback value into the space provided.

Press in sequence from low to high fire. At each stage enter the feedback value for the gas actuator once stabilized.

Once complete, press Start Setup to release.

#### **COMBUSTION OFFSETS**

Access the Combustion Setup page by pressing the Right arrow key on the computer.

For initial testing, to avoid high levels of CO overloading the analyzer at high fire, increase the 'PacMan' opening to near fully open before starting.

For low fire, there is a risk of excessive levels of CO produced. To avoid potential high levels of CO, reduce the gas offset on all remaining combustion settings (55, 25 and 10%). If using a Maxitrol modulating valve, reduce by approximately 20-30mA.

Connect analyzer to flue. Enable the fan and heat switch.

Press: Service Mode and High Fire.

The burner will be enabled to prepurge and ignition.

Allow the heat exchanger to warm up a few minutes.

#### **△** CAUTION:

Be aware of high discharge temperatures. High limit failure may occur.

Adjust regulator to achieve design manifold pressure. Adjust the 'PacMan' to achieve a high fire air level between  $3.5 - 4.5\% O_2$ .

Calculate and clock the high fire gas flow. Adjust regulator as required and re-clock. Once set, lock the 'PacMan' in place.

Follow the sequence noted below exactly and set to the approximate O<sub>2</sub> values noted by adjusting

the air and gas offsets as required. Recalculate and record clocking value to match percentage of fuel at each level.

# **⚠** NOTICE:

Important: remember to un-click the previous gas position button once you have clicked on the next position.

Position	%O <sub>2</sub>	
Near High Fire 90%	3.8 - 4.8	
Low Fire 4%	16.8 - 17.3	
Near Low Fire 10%	15.0 - 16.0	
Medium Fire 1 25%	10.5 - 12.5	
Medium Fire 2 55%	7.0 - 8.5	

Once the above values have been confirmed and set, again press **High Fire** button, and allow  $O_2$  levels to stabilize. Press **Low Fire**, and release the **High Fire** button. As the burner reduces to low fire, observe  $O_2$  levels to ensure they do not drop below the high fire  $O_2$  setting by more than 0.3. If this occurs there is air fuel curve error and must be reset with the above steps.

Low fire combustion blower speed should not be lower than 950 rpm.

Press: Setup Complete.

Press to disable Service Mode.

Return to the home screen by pressing the **Left** arrow key, and then press **Save User Settings**.


Combustion setup is now complete.

# **ALARM DESCRIPTION**

Gas Valve Wiring	Gas valve feedback has power before the FR and SR contact are
Gas valve willing	energized.
Shorted Air proving	Combustion blower feedback exceeds 500 rpm for more than 60 seconds
Shorted All proving	when there is no demand.
Open Air Proving	Combustion blower does not exceed 3000 rpm during purge.
60 Hz	Combustion blower frequency has exceeded 60 Hz ( 3590 RPM)
Plugged Condensate	Blocked condensate sensor reads less then $7k\Omega$ for more than 5 minutes.
Blocked Flue	Blocked flue input has been enabled for 3 minutes or more.
Flame Relay Wiring	Received a gas valve feedback within 500ms of activating the flame relay
I taille ketay Willing	output.
Flame Failure	Gas valve feedback has no power after 1 minute of enabling the Flame
Traine raiture	relay output.
Gas Valve out of range	When ball valve is enabled this alarm occurs if the gas actuator feedback
das valve out of fallge	is greater or less then the demand by 10% for more than 90 seconds.

#### **G-XM**

For indirect heating appliances with DG, and DJ (X) style burners size 200 and above.



#### **BASIC OPERATION**

On a call for heating the combustion blower will be enabled and the air actuator will open to the prepurge setpoint to purge the heat exchanger. Once the prepurge time has elapsed the gas and air actuators will move to ignition position and then enable the ignition control to start and prove pilot flame, then open the main safety valve (SSOV). Once the pilot flame has proven and the main flame is established, the G-XM will then disable the pilot valve. The burner is allowed to operate to maintain the requested discharge air temperature from the CenCon by modulating the gas and air actuators. If heating is not required the burner will be disabled and the combustion blower will enter a post purge time, and then shut down.

# **G-XM TIMING**

Prepurge	60 seconds
Post purge	5 minutes
Flame failure	15 seconds lockout on ignition control and 60 seconds on burner
Pilot opening time	8 seconds
Open combustion air	60 seconds
proving	oo seconds
Improper gas valve wiring	2 seconds
Blocked condensate trip	5 minutes
Blocked flue	10 seconds trip and 1 minute burner alarm
Heat exchanger cool down	90 seconds if the discharge air is above 50° (10°C), else none.
Heat exchanger warm up	75 seconds if ambient air is less than 40°F (4°C) and discharge temperature less
fan delay	than 90°F (32°C), else no warm up.
Burner cool down	90 seconds

# **TERMINAL DESCRIPTION**

Terminal	Type	Name	Description	Value
HN		Power Supply		24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
FbG	Al	Feedback Gas	Compares the ball valve actuator feedback signal to the demand signal.	0-10 Vdc
FbA	Al	Feedback Air	Compares the combustion air actuator feedback signal to the demand signal.	0-10 Vdc
MBV	AO	Modulating ball valve	Modulating gas valve actuator output.	0-10 Vdc
MCA	AO	Modulating combustion air	Modulating combustion air actuator output.	0-10 Vdc
CAS	DI	Combustion air switch	Optional proof of combustion air flow.	24 Vac
BFS	DI	Blocked flue switch	Normally closed, opens on blocked flue.	24 Vac
EnH	DI	Enable heat	24V must be applied to allow heating function.	24 Vac
CB1, CB2	DO	Combustion blower	Start contact for the combustion air motor contactor.	24/120 Vac
PV1, PV2	DO	Pilot valve	Disables the pilot flame once the main burner has been established.	24/120 Vac
SR1, SR2	DO	Safety relay	Secondary safety lockout contacts	24/120 Vac
FR1, FR2	DO	Flame relay	Flame relay enable contacts.	24/120 Vac
FbV	DI	Feedback valve	Feedback signal from the safety shut off valve (SSOV). Wired directly to valve.	24/120 Vac
VN		Valve neutral	Neutral feedback signal from the safety shut off valve (SSOV).	
HL	DI	High limit	Normally closed, opens on high temperature.	24 Vac
СР	Al	Condensate probe	Condensate probe sensor input.	Ohms (Ω)

#### G-XM COMBUSTION SETUP

Combustion setup may only be done using a computer.

#### **⚠** NOTICE:

Always allow the heat exchanger temperature to stabilize before accepting combustion values.

A set of full clocking data must be completed in test bay to generate a data base of combustion fuel curves.

#### GAS AND AIR ACTUATOR CALIBRATION

#### **⚠** WARNING:

If using a ball valve and actuator for gas or air, it must be pre-calibrated before attempting to set combustion offsets. This is normally completed at initial factory setup, but will also need to be verified if the actuator is replaced.

For field serviced, record all offset values, and then set all values to zero for both the gas and air actuators. Enter calibration screen and perform calibration setup. Return and re-set offset values.

# **⚠** WARNING:

Before performing the calibration procedure, turn Off the appliance gas supply.

Power the CenCon, leave the heat switch and fan switch off. Turn off the gas supply to the appliance.

Press the UP arrow to enter the Actuator Calibration screen.

Press: Start Setup, then Closed (0%)

Both actuators will move to fully closed (90°) position, and read 2V. Set the ball valve and combustion air damper to fully closed mechanically, and tighten linkage. The feedbacks must be at or very near 2V. Enter the actual feedback values into the spaces provided.

Press in sequence from low to high fire. At each stage enter the feedback values for both the gas and air actuators once stabilized.

Once complete, press **Start Setup** to release. Turn the gas supply back ON.

#### **COMBUSTION OFFSETS**

Access the combustion setup page by pressing the Right arrow key on the computer.

Connect analyzer to flue.

Enable the fan and heat switch.

Press: Service Mode and High Fire.

The burner will be enabled to prepurge and ignition.

Allow the heat exchanger to warm up a few minutes.

From this point begin setup.

#### **A** CAUTION:

Be aware of high discharge temperatures. High limit failure may occur.

Adjust regulator to achieve design manifold pressure and suggested oxygen levels of 3.5 -4.5%. Once stabilized clock input. Readjust regulator or air offset if required.

To adjust the high fire air use High Fire Air Offset value.

Follow the sequence noted below exactly and set to the approximate O<sub>2</sub> values noted by adjusting the air and gas offsets as required. Recalculate and record clocking value to match percentage of fuel at each level.

Important: remember to un-click the previous gas position button once you have clicked on the next position.

%O<sub>2</sub>

**Position** 

# CenCon

# **Enga** Engineered air

Near High Fire 90%	3.8 - 4.8	
Low Fire 4%	16.8 - 17.3	
Near Low Fire 10%	15.0 - 16.0	
Medium Fire 1 25%	10.5 - 12.5	
Medium Fire 2 55%	7.0 - 8.5	

Once the above values have been confirmed and set, again press **High fire** button and allow  $O_2$  levels to stabilize. Press **Low Fire**, and release the **High fire** button. As the burner reduces to low fire, observe  $O_2$  levels to ensure they do not drop below the high fire  $O_2$  setting by more than  $O_3$ . If this occurs there is air fuel curve error and must be reset with the above steps.

Press: Setup Complete.

Press to disable Service Mode.

Return to the home screen by pressing the **Left** arrow key, and then press Save User Settings.

Combustion setup is now complete.

#### **⚠** NOTICE:


The **Tracking Okay** light indicates the stroke time of the actuators are in sync, within 5%. If not illuminated, one actuator is waiting for the other to catch up.

# **ALARM DESCRIPTION**

Converse to Converse	Gas valve actuator feedback is greater or less then the demand .		
Gas Valve out of range	Tolerances and timing depending vary on mode of operation.		
Air Actuator Out of range	Air Actuator Feedback Is greater or less then the demand. Tolerances and		
Air Actuator Out of range	timing vary depending on mode of operation.		
Shorted Air Proving	Combustion blower air switch input has power for 10 seconds before the		
Shorted Air Proving	combustion blower has been commanded on.		
	Combustion blower air switch input has no power for 60 seconds after		
Open Air Proving	commanding the combustion blower on / Combustion blower air switch		
	input has no power for 2 seconds during main flame		
Plugged Condensate	Blocked condensate sensor reads less than 7kohms for more than 5		
r tagged condensate	minutes.		
Blocked Flue	cked Flue Blocked flue input has been enabled for 1 minute or more.		
Flame Relay Wiring	Received a gas valve feedback within 500ms of activating the Flame relay		
rtaine Retay Willing	output.		
Flame Failure	Gas valve feedback has no power after 1 minute of enabling the Flame		
Traine Faiture	relay output.		
Gas Valve Wiring	Gas valve feedback has power before the FR and SR contact are		
Gas valve willing	energized.		

#### M-XM

For direct fired HE style direct fired heaters.



#### **BASIC OPERATION**

On a call for heating, and with the supply blower enabled, the ignition control will be enabled to start and prove pilot flame, then open the main safety valve (SSOV). Once the pilot flame has proven and the main flame is established, the M-XM will then disable the pilot valve. The burner is allowed to operate to maintain the requested discharge air temperature from the CenCon by modulating the control valve.

Cycling a direct fired burner will often cause undesirable fuel odorants to enter the occupied space. When in heating mode, direct fired appliances rely on a high turndown ratio of fuel control to maintain the discharge air temperature setpoint. The heating may be disabled by either a predetermined ambient lock out setpoint, or external contacts or switches connected to terminal EnH. The default ambient heating lockout setpoint (typically 65°F) is field adjustable only through a computer connection service interface.

# M-XM / P-XM TIMING

Flame failure alarm	15 seconds lockout on ignition control	
Traine raiture atairii	60 seconds on burner	
Pilot opening time	10 seconds	
Mode change time	60 seconds	
Damper delay off	20 seconds	
Improper gas valve wiring alarm	2 seconds	
Supply air low airflow alarm	30 seconds	
Shorted damper end switch alarm	1 second	
Supply air shorted air switch alarm	30 seconds	

# **TERMINAL DESCRIPTION**

Terminal	Type	Name	Description	Value
HN		Power Supply		24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
FbG	Al	Feedback Gas	Compares the ball valve actuator feedback signal to the demand signal.	0-10 Vdc
MBV	AO	Modulating ball valve	Modulating gas valve actuator output.	0-10 Vdc
MPP	AO	Profile pressure	Modulating profile pressure damper actuator output	0-10 Vdc
HiE	DI	High Speed Enable	Initiate high speed operation.	24 Vac
EnH	DI	Enable heat	24V must be applied to allow heating function.	24/120 Vac
CM	COM	Relay Common	Relay input power common to digital outs	24/120 Vac
HiS	DO	High Speed	High speed fan start contact	24/120 Vac
Exl	DO	Exhaust fan low	Single or low speed exhaust fan start contact	24/120 Vac
DFR	DO	Dual Flame Rod	Relay output to switch flame rods.	24/120 Vac
WPu	DO	Water Pump	Enable evaporative 'swamp' cooler water pump.	24/120 Vac
PV1, PV2	DO	Pilot valve	Disables the pilot flame once the main burner has been established.	24/120 Vac
SR1, SR2	DO	Safety relay	Secondary safety lockout contacts	24/120 Vac
FR1, FR2	DO	Flame relay	Flame relay enable contacts.	24/120 Vac
FbV	DI	Feedback valve	Feedback signal from the safety shut off valve (SSOV). Wired directly to valve.	24/120 Vac
VN		Valve neutral	Neutral feedback signal from the safety shut off valve (SSOV).	
HL	DI	High limit	Normally closed, opens on high temperature.	24 Vac
MX1, MX2	AO	Maxitrol Valve	DC current output to the Maxitrol modulating valve.	mA

#### M-XM BURNER SETUP

Combustion setup may only be done using a computer.

#### **MAXITROL VALVE**

Power the CenCon and enable the fan switch.

Connect computer to CenCon.

Set airflow as required. Confirm profile pressure drop is within proper range. If using a Belimo gas valve actuator, perform the **Ball Valve Actuator Calibration** first.

Access the burner setup screen by pressing the **Right** arrow computer key.

Enable the heat switch.

Press **Service Mode**, then **High Fire**. The burner will initiate the ignition sequence.

Adjust the service regulator to achieve design manifold pressure. Clock the gas flow and adjust as necessary.

Press **Low Fire**. Set low fire using the mechanical bypass on the Maxitrol valve. The flame should be as small as possible while still maintaining a stable flame across the entire burner.

Press **Setup Complete**.

Return to the home screen and allow the unit to operate independently.

#### **GAS ACTUATOR CALIBRATION**

#### **MARNING:**

If using a ball valve and actuator for gas it must be pre-calibrated before attempting to set combustion offsets. This is normally completed at initial factory setup, but will also need to be verified if the actuator is replaced.

For field serviced, record all offset values, and then set all values to zero for the gas actuators. Enter calibration screen and perform calibration setup. Return and re-set offset values.

# **⚠** WARNING:

Before performing the calibration procedure, turn Off the appliance gas supply.

Power the CenCon, leave the heat switch and fan switch off. Turn off the gas supply to the appliance.

Press the **UP** arrow to enter the actuator calibration screen.

Press: Start Setup, then Closed (0%)

The gas actuator will move to fully closed (90°) position, and read 2V. Set the ball valve to fully closed mechanically, and tighten linkage. The feedback must be at or very near 2V. Record the feedback in the space provided.

Press in sequence from low to high fire. At each stage enter the feedback values for the gas actuator.

Once complete, press **Start Setup** to release, and then press the **Down** arrow.

Enable the heat switch. Press **Service Mode**, then **High Fire**.

The ball valve will move to 100% open. Adjust the appliance regulator to achieve the design manifold pressure. Clock the gas flow and adjust as necessary.

Press Low Fire. Set low fire by adjusting the gas offset valve next to the Low Fire window, under Gas Offsets. The flame should be as small as possible while still maintaining a stable flame across the entire burner.

Press: Setup Complete.

Press to disable Service Mode.

Return to the home screen by pressing the **Left** arrow key, and then press **Save User Settings**.

Combustion setup is now complete.

# **ALARM DESCRIPTION**

Flame Failure	Gas valve feedback has no power after 1 minute of enabling the Flame relay output.	
Gas Valve Wiring	Gas valve feedback has power before the FR and SR contact are energized.	
Flame Relay Wiring	Received a gas valve feedback within 500ms of activating the Flame relay output.	
Gas Valve out of range	When ball valve is enabled this alarm occurs if the gas actuator feedback is greater or less then the demand by 10% for more then 60 (Default is currently variable) seconds.	
Low Velocity Air Switch	Velocity Air Switch Occurs if the pressure drops below the low pressure setpoint during modulation for more than 40 seconds	
High Velocity Air Switch	Occurs if the pressure goes above the High pressure setpoint during modulation for more than 90 seconds	
Air Tube	Unexpected sensing. Typically reversed sensor connections.	
Low Pressure	Alarm occurs if the pressure is less than the low pressure setpoint plus 0.05" wc after the damper is opened and the blower has been commanded to start for a minute. This alarm will not be triggered if we have already passed the purge status and have lit. See Low velocity air Switch alarm	
Low Pressure Sensor	Pressure Sensor If the pressure is greater than the Very low pressure setpoint before the damper is opened for more than 1 minute.	
Very Low Pressure	Occurs if the pressure drops below the very low pressure setpoint after the purge has been completed.	
Far Sensor Flame Failure	Occurs if a secondary flame rod is enabled and we lose flame sensing in less than 20 seconds after the pilot valve drops out on consecutive attempts.	

# **Profile Pressure Setpoint**

Non-adjustable trip setpoints noted in the table below, measured as in.wc. (Pa). If the unit is designed for variable air volume, the pressure trip points are scaled slightly to allow the profile damper actuator time to move and rebalance the profile pressure drop.

	Natural Gas	Propane
Very Low	0.12 (30)	0.17 (42)
Low	0.18 (45)	0.25 (62)
High	0.75 (187)	1.00 (249)


Time to trip on failures:

Heating Enabled	Response Time
Actual less than Very Low	1 Second
Actual less than Low	40 Seconds
Actual greater than High	90 Seconds

No Heat (Ventilation)	Response Time
Actual less than Very Low	1 Minute
Actual less than Low	1 Minute
Actual greater than High	No failure

## C-XM

For direct expansion mechanical cooling operation, including FW, UPW and CU style equipment.



### **BASIC OPERATION**

For staged compressor operation the C-XM will sequence on and off compressor stages to attempt to maintain the discharge temperature setpoint. As with all staged systems, expect the discharge temperature to fluctuate from setpoint as compressors are turned on and off. The C-XM can stage up to 6 compressors. A second C-XM may be added for equipment with more than 6 stages.

### **C-XM TIMING**

Anti-cycle time	
Inter-stage time	5 minutes

# **TERMINAL DESCRIPTION**

Terminal	Type	Name	Description	Value
HN		Power Supply	24Vac Grounded Neutral	24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
МСр	AO	Modulating compressor	Analog output to modulating compressor.	0-10 Vdc
MF1	АО	Modulating condenser fan #1	Analog output to variable speed condenser fan.	0-10 Vdc
MF2	AO	Modulating condenser fan #2	Analog output to variable speed condenser fan.	0-10 Vdc
MRh	AO	Modulating reheat output	Modulating hot gas reheat output.	0-10 Vdc
HP1	Al	High pressure sensor #1	Analog discharge pressure transducer, circuit #1.	0-10 Vdc
HP2	Al	High pressure sensor #2	Analog discharge pressure transducer, circuit #2.	0-10 Vdc
HP3	Al	High pressure sensor #3	Analog discharge pressure transducer, circuit #3.	0-10 Vdc
HP4	Al	High pressure sensor #4	Analog discharge pressure transducer, circuit #4.	0-10 Vdc
+5V		+5 Vdc	DC 5V power source.	
СМа	СОМ	Common to output set 'a'	Common power relays 'a'.	24/120 Vac
C1a	DO	Cooling stage #1	Output stage #1 cooling, powered from common 'a'.	24/120 Vac
C2a	DO	Cooling stage #2	Output stage #2 cooling, powered from common 'a'.	24/120 Vac
C3a	DO	Cooling stage #3	Output stage #3 cooling, powered from common 'a'.	24/120 Vac
C4a	DO	Cooling stage #4	Output stage #4 cooling, powered from common 'a'.	24/120 Vac
C5a	DO	Cooling stage #5	Output stage #5 cooling, powered from common 'a'.	24/120 Vac
F1b	DO	Condenser fan stage #1	Ambient temperature based condenser fan #1 enable.	24/120 Vac
F2b	DO	Condenser fan stage #1	Ambient temperature based condenser fan #2 enable.	24/120 Vac
C6a	DO	Cooling stage #6	Output stage cooling, stage #6, powered from common 'a'.	24/120 Vac
R1b	DO	Stepped reheat stage #1	Stepped reheat output, stage 1, powered from common 'b'.	24/120 Vac
R2b	DO	Stepped reheat stage #2	Stepped reheat output, powered from common 'b'.	24/120 Vac
CMb	COM	Common to output set 'b'	Common power relays 'b'.	24/120 Vac
SSR	DO	Digital output	Solid state relay for digital compressors.	
HP5	Al	High pressure sensor #5	Analog discharge pressure transducer, circuit #5.	0-10 Vdc
LP1	Al	Low pressure sensor #1	Analog suction pressure transducer, circuit #1.	0-10 Vdc

LP2	Al	Low pressure sensor #2	Analog suction pressure transducer, circuit #2.	0-10 Vdc
LP3	Al	Low pressure sensor #3	Analog suction pressure transducer, circuit #3.	0-10 Vdc
LP4	Al	Low pressure sensor #4	Analog suction pressure transducer, circuit #4.	0-10 Vdc
LP5	Al	Low pressure sensor #5	Analog suction pressure transducer, circuit #5.	0-10 Vdc
+5V		+5 Vdc	DC +5 power source	5 Vdc
GC		DC common	DC common	
DS+-	Al	Dehumidify Setpoint	0-100%RH Setpoint for dehumidification operation.	0-10 Vdc
EnH	DI	Enable reheat	Enable / disable hot gas reheat.	24 Vac
EnC	DI	Enable cooling	Enable / disable mechanical cooling.	24 Vac
CW1,2	Al	Chilled Water sensor	10k Type 2 thermistor	Ohms (Ω)

#### STAGED COMPRESSORS

On a call for cooling, the compressors will stage on from 1 to 6. The CenCon cooling programming does not allow for random start, only sequential. Inter-stage and anti-cycle timing is built into the CenCon program and is not adjustable.

On the initial call for cooling only, the inter-stage time of the first 2 stages is decreased.

### **AMBIENT CONDENSER FANS**

The CenCon may incorporate up to 2 ambient temperature based condenser fan (or ambient based compressors) enable contacts.

### LOW AMBIENT LOCKOUT

Mechanical cooling is disabled below the design low ambient lockout setpoint, typically set at  $50^{\circ}F$  ( $10^{\circ}C$ ), and  $58^{\circ}F$  ( $14^{\circ}C$ ) for makeup air appliances.

#### **CONDENSER REHEAT**


When dehumidification is enabled (digital input), and there is a call for dehumidification from the return or room air humidistat, the CenCon will enable the condenser reheat controller (Carel CRC) and stage on compressors to obtain the pre-cool (DX) leaving temperature. The condenser reheat controller will modulate the reheat compressor's head pressure at or above 350 psi. The CenCon will modulate the output signal to the CRC to operate the reheat valve to maintain the requested discharge set point.

Appliances may have an added auxiliary heat option that will allow the main source of heat to be enabled if reheat is at 100% and the desired discharge setpoint cannot be attained.

The compressor oil return cycle is managed by the CRC. Refer to the Engineered Air Carel Condenser Reheat manual.

## H-XM

For control of staged electric heat (LMK and /K) appliances.



### **BASIC OPERATION**

For staged electric heater operation the H-XM will sequence on and off stages of electric heat to attempt to maintain the discharge temperature setpoint. As with all staged systems, expect the discharge temperature to fluctuate from setpoint as stages are turned on and off. The H-XM can stage up to 7 stages of electric heat. Additional stages are typically based on ambient temperature.

### **TERMINAL DESCRIPTION**

Terminal	Type	Name	Description	Value
HN		Power Supply	24Vac Grounded Neutral	24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
SCR	AO	Modulating	Modulating output to external SCR controller.	0-10 Vdc
Jek	AO	output	modulating output to external ser controller.	0 10 vac
EnH	DI	Enable heat	24V must be applied to allow heating function.	24/120 Vac
CMa	СОМ	Common to	Common power relays 'a'.	24/120 Vac
CMa	COM	output 'a'.	Common power retays a .	24/ 120 Vac
H1a	DO	Heating stage #1	Output stage #1 heating, powered from common 'a'.	24/120 Vac
H2a	DO	Heating stage #2	Output stage #2 heating, powered from common 'a'.	24/120 Vac
H3a	DO	Heating stage #3	Output stage #3 heating, powered from common 'a'.	24/120 Vac

H4a	DO	Heating stage #4	Output stage #4 heating, powered from common 'a'.	24/120 Vac
CMb	COM	Common to output set 'b'	Common power relays 'b'.	24/120 Vac
H5b	DO	Heating stage #5	Output stage #5 heating, powered from common 'b'.	24/120 Vac
СМс	COM	Common to output set 'c'	Common power relays 'c'.	24/120 Vac
Н6с	DO	Heating stage #6	Output stage #6 heating, powered from common 'c'.	24/120 Vac
CMd	COM	Common to output set 'd'	Common power relays 'd'.	24/120 Vac
H7d	DO	Heating stage #7	Output stage #7 heating, powered from common 'd'.	24/120 Vac
DSw	DI	Door Switch	External safeties input.	24/120 Vac
HLN		High limit neutral	External safeties input neutral.	24/120 Vac
HL	DI	High Limit	Normally closed, opens on high temperature.	24/120 Vac

### **STAGED HEATING**


Inter-stage timing is non-adjustable, however the timers may be truncated on initial startup depending on the level of temperature demand.

# **HIGH AMBIENT LOCKOUT**

Electric heating is disabled above the design high ambient lockout setpoint.

## S-XM

For control of gas fired SH and SHX humidifiers.



### **BASIC OPERATION**

The S-XM expansion module controls the operation of SH and SHX series gas fired humidifiers. This includes tank water fill and drain and burner control. On a call for humidification the tank first fills with water, then the burner gas-fired heat is enabled to produce steam. Water level is controlled by the water level probes. Water quality dictates the minimum tank drain cycle times. Drain temperature is monitored and cooled with the supply water if required.

# S-XM TIMING

	Less than 60 ppm = 30 hours
Dump Schedule (ppm of calcium	60 - 119 ppm = 20 hours
carbonate - pre-programmed)	120 - 179 = 15 hours
	180 or greater = 10 hours
Drain initiation contact (OCC)	30 seconds
confirm delay time	30 Seconds
Drain time	SH_240 and smaller = 20 minutes
Drain time	SH_400 and larger = 40 minutes
Fill time	30 - 60 minutes
Pilot opening time	10 seconds
Improper gas valve wiring alarm	2 seconds

# **OPERATION NOTES**

The S-XM can control both the large (120-650) and small (35-90) sizes of humidifiers. The large sizes use a DJ style burner and require the addition of a J-XM and CD-XM expansion module.

# **TERMINAL DESCRIPTION**

Terminal	Type	Name	Description	Value
HN		Power Supply	24Vac Grounded Neutral	24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
MHL	4.1	Modulating High	Optional analog input for duct mounted high	0-10 Vdc
MIL	Al	Limit	humidity sensing.	
FbG	Al	Feedback Gas	Compares the ball valve actuator feedback signal to the demand signal.	0-10 Vdc
MBV	AO	Modulating Ball Valve	Modulating gas valve actuator output.	0-10 Vdc
BFS	DI	Blocked Flue Switch	Normally closed, opens on blocked flue.	24 Vac
EnH	DI	Enable heat	24V must be applied to allow heating function.	24 Vac
CM	COM	Relay Common	Relay input power common to valve outputs.	24/120 Vac
FV	DO	Fill Valve	Enable water fill valve.	24/120 Vac
MV	DO	Mixing Valve	Enable drain water tempering valve.	24/120 Vac
DV	DO	Drain Valve	Enable primary drain valve.	24/120 Vac
FVS	DO	Fill Valve Side	Enable side tank (SHX) fill valve.	24/120 Vac
PV1, PV2	DO	Pilot valve	Disables the pilot flame once the main burner has been established.	24/120 Vac
SR1, SR2	DO	Safety relay	Secondary safety lockout contacts	24/120 Vac
FR1, FR2	DO	Flame relay	Flame relay enable contacts.	24/120 Vac
FbV	DI	Feedback valve	Feedback signal from the safety shut off valve (SSOV). Wired directly to valve.	24/120 Vac
VN		Valve neutral	Neutral feedback signal from the safety shut off valve (SSOV).	
HL	DI	High limit	Normally closed, opens on high temperature.	24 Vac
DH+,DH-	Al	Direct Humidity	Input for direct control of humidifier output control.	0-10 Vdc
Dn1, Dn2	Al	Drain Sensor	Drain probe sensor input.	Ohms (Ω)
СР	Al	Condensate probe	Condensate probe sensor input.	Ohms (Ω)
FWP	Al	Water probe	Fill water level sensor	Ohms (Ω)
LWP	Al	Water probe	Low water level sensor	Ohms (Ω)
MX1, MX2	AO	Maxitrol Valve	DC current output to the Maxitrol modulating valve.	mA
ECO	AO	ECM Demand	Electronically Commutated burner motor control output signal.	0-10 Vdc
PWM	PWM	ECM rpm feedback	Pulse width modulation feedback signal from Electronically Commutated burner motor.	PWM
ECC		ECM Neutral	Neutral reference to ECO output signal.	

### S-XM BURNER SETUP

Combustion setup may only be done using a computer. Refer to the J-XM burner setup for larger SH and SHX humidifiers (sizes 120 - 650). The following is for the small versions (sizes 35-90) which have a turndown of 3:1.

Power the CenCon and enable the fan switch.

Connect computer to CenCon.

Access the burner setup screen by pressing the **Right** arrow computer key.

Enable the heat switch.

Press Service Mode, then High Fire.

The burner ignition module will be enabled to start the ignition sequence and monitor the air proving switch. Adjust the service regulator to achieve design manifold pressure. Clock the gas flow and adjust as necessary. Adjust high fire air with the combustion air blower inlet slider to  $3.5 - 4.5\% \ O_2$ . Re-clock gas flow and screw the inlet slider in place.

Press Low Fire. Low fire gas pressure is set by using the mechanical bypass on the Maxitrol valve. Air flow is not adjustable and should be between 9-12%  $O_2$ .

Press: Setup Complete.

Press to disable Service Mode.

Return to the home screen by pressing the **Left** arrow key, and then press **Save User Settings**.


Combustion setup is now complete.

### **ALARM DESCRIPTION**

Drain Sensor Failure	Sensor reads <30°F or >212°F for more than 10 seconds.	
Tank High Pressure Overflow	Unexpected hot water reading at drain sensor. Drain temperature has	
Talik High Flessure Overflow	been >110°F after the burner has been on for more than 5 minutes.	
Fill Valve Stuck Open	Unexpected hot water reading at drain sensor. Drain temperature is	
The valve stuck open	>110°F, both LWP and FWP probes are covered, and SH status is OFF.	
	Drain tempering valve appears to not function. Drain temperature senses	
Hot Drain Lockout	>130°F for more than 1 minute. Attempts to drain 15 times, then locks	
	out for 2 hours before retrying drain attempt.	
	If during steam production the low water probe (LWP) is uncovered in the	
Foaming Alarm	first 2 minutes of the fill valve being turned on, after the burner has been	
	on for longer than 10 minutes.	
Water Probe Sequence	During fill, if the FWP is made before the LWP.	
Failure to Drain	The drain valve has been enabled for more than 1 hour and the LWP is	
Tallare to Dialii	still covered.	
Tank High Limit	Tank high limit temperature switch open. Manual reset.	
	On initial fill, if the LWP is not covered within the full fill time.	
Failed Water Supply	During normal steam production, alarm occurs if FWP is not covered after	
	5 minutes of fill command.	

## **ER-XM**

For control of energy recovery systems, including wheels, pipes and plates.



### **BASIC OPERATION**

On a call for energy recovery, with the enable contact closed, the ER-XM will command the energy recovery method to try and achieve control (heat wheel motor speed, heat pipe tilt actuator, heat plate damper actuator) to discharge setpoint. Exhaust temperature is monitored for performance and frost protection.

The leaving air temperature is primarily for independent heat wheel systems. In a packaged unit the discharge sensor is used for control. In a packaged unit the leaving air sensor is for calculating performance.

An optional rotational sensor can be added to the heat wheel for indication of rotation and speed.

# **TERMINAL DESCRIPTION**


Terminal	Type	Name	Description	Value
HN		Power Supply		24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
		Modulating		
MFr	AO	Bypass Damper	Modulating output to bypass damper actuator.	0-10 Vdc
		Demand		
MER	AO	Drive Motor	Modulating output to heat wheel drive motor, heat	0-10 Vdc
MLK	AU	Speed Signal	pipe tilt actuator, or heat plate damper actuator.	0-10 vac
EnH	DI	Enable energy	Enable energy recovery operation.	24 Vac
LIIII	DI	recovery	Enable energy recovery operation.	Z+ Vac
Rot	DI	High Speed	Input from rotation sensor.	24 Vac
Noc	Di	Enable	input from rotation sensor.	Z+ vac
CM / ByD	DO	Bypass Damper	Dry contact enable bypass damper.	24/120 Vac
CM / ERC	DO	Relay Common	Dry contact enable wheel motor starter.	24/120 Vac
		Leaving		
LA1,2	Al	(Supply) Air	10k Type 2 thermistor	Ohms (Ω)
		Temperature		
EA1,2	Al	Exhaust Air	10k Type 2 thermistor	Ohms (Ω)
EAI,Z	AI	Temperature	Tok Type 2 thermistor	O111113 (12)

# **ALARM DESCRIPTION**

Sensor Failure	Exhaust or Leaving wheel sensor open or shorted.			
Defrost Active	Temperatures approaching frost temperature. Control signal reduces.			

## **XP-XM**


An expansion module was developed primarily to allow the addition of BACnet (EMS) points not currently available on the CenCon. These points are for monitoring only, or command points from the front end BACnet system. Up to a maximum of (4) XP-XM expansion modules may be used on a single system. Custom programming for functional operation of these points is not available.



Terminal	Type	Name	Description	Value
HN		Power Supply	24Vac Grounded Neutral	24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
S1	Al	Sensor 1	10k Type 2 thermistor	Ohms (Ω)
S2	Al	Sensor 2	10k Type 2 thermistor	Ohms (Ω)
Al1+/-	Al	Analog Input 1	Analog input, high common mode	0-10 Vdc
Al2+/-	Al	Analog Input 2	Analog input, high common mode	0-10 Vdc
AI3+/-	Al	Analog Input 3	Analog input, high common mode	0-10 Vdc
Al4+/-	Al	Analog Input 4	Analog input, high common mode	0-10 Vdc
DI1	DI	Digital Input 1	Normally open input contacts	24 Vac
DI2	DI	Digital Input 2	Normally open input contacts	24 Vac
DI3	DI	Digital Input 3	Normally open input contacts	24 Vac
DI4	DI	Digital Input 4	Normally open input contacts	24 Vac
AO1+/-	AO	Analog Output 1	Analog output	0-10 Vdc
AO2+/-	AO	Analog Output 1	Analog output	0-10 Vdc
CM	COM	Relay Common	Relay input power common to digital outputs	24 Vac
DO1	DO	Digital Output 1	Normally open output contacts	24 Vac
DO2	DO	Digital Output 2	Normally open output contacts	24 Vac
DO3	DO	Digital Output 3	Normally open output contacts	24 Vac
DO4	DO	Digital Output 4	Normally open output contacts	24 Vac

## **CD-XM**

TRIAC combustion motor speed drive. The 120V and CB terminals as separated to accept heavy insulation wire from the combustion blower motor. The CD-XM will be mounted in the electrical panel on 'standard' equipment. The CD-XM must always be mounted such that the speed sensor wire does not need to be extended, therefore it may be mounted inside the burner cabinet in equipment that has the burner control panel mounted farther away. If so, keep at least 6" (150mm) aware from the ignition control.




### **BASIC OPERATION**

The Chopper Drive module will control the combustion motor speed on DJ indirect fired burners in conjunction with the J-XM heating module. A 3 wire feedback signal from the Engineered Air DJ hall-effect speed sensor is used to prove the actual blower speed.

Terminal	Type	Name	Description	Value
ΗN		Power Supply	24Vac Grounded Neutral	24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
OS	Al	Tachometer +	Engineered Air DJ speed sensor Red wire.	0-10 Vdc
YS	Al	Tachometer -	Engineered Air DJ speed sensor Yellow wire.	0-10 Vdc
GS	Al Tachometer reference	Tachometer	Engineered Air DJ speed sensor Green wire.	0-10 Vdc
G5		reference	Liigineered Air Do speed sensor dreen wire.	0-10 vac
СВ	AO	TRIAC output	Output to combustion blower motor.	120 Vac
120		120V line in	120V Hot input	120 Vac
SR1,2	DO	Safety relay	Normally open output contacts	24/120 Vac

## P-XM

Pressure sensing module. The P-XM can output either a dry on/off contact or a modulating 0-10Vdc output corresponding to 0-10mbar (0-4"wc) differential pressure. The CenCon and monitor up to (7) P-XM modules to provide filter monitoring or differential pressure readings.



### **BASIC OPERATION**

The Pressure module will measure the required variable flow in a direct fired heater using the M-XM heating module. The P-XM has an internally mounted air pressure sensor rated at an output of 0-10mbar (0-4"wc).

⚠ CAUTION: Do not blow into the pressure ports. Excessive pressure and moisture will damage it. The ports are fragile and should not be tampered with.

At power start up, the P-XM will perform a snap check of the pressure sensor (near 0.0 pressure differential). Primarily for testing for kinked tubing, if any pressure is present at the sensor the yellow light will turn on solid for 2 seconds then revert to normal operation. It then ignores the pressure sensing output until after the supply blower starts. It then ensures the pressure differential across the profile is within operating range before allowing the heat to be enabled.

The CenCon air pressure monitoring system performs a time weighted calculation based on severity of change to provide some protection against nuisance lock outs from various sources, such as wind gusts. Once the airflow has stabilized, the timer is reset. For timing values refer to the M-XM alarm list.

Terminal	Type	Name	Description	Value
HN		Power Supply	24Vac Grounded Neutral	24 Vac
GND		Ground	Connect to chassis.	
LmA B		Modbus	Internal Network	
CM		Relay Common	Common contact input to Pressure Switch	24/120 Vac
PSw	DO	Pressure Switch	Output contact	24/120 Vac
PrS	AO	Pressure Sensor	Pressure sensor output 0-4"w.c.	0-10 Vdc

# **Appendix A - Thermistor Output Table**

°F	°C	Ω
-39	-39.4	323839
-37	-38.3	300974
-35	-37.2	279880
-33	-36.1	260410
-31	-35.0	242427
-29	-33.9	225809
-27	-32.8	210443
-25	-31.7	196227
-23	-30.6	183068
-21	-29.4	170775
-19	-28.3	159488
-17	-27.2	149024
-15	-26.1	139316
-13	-25.0	130306
-11	-23.9	121939
-9	-22.8	114165
-7	-21.7	106939
-5	-20.6	100218
-3	-19.4	93909
-1	-18.3	88090
1	-17.2	82670
3	-16.1	77620
5	-15.0	72911
7	-13.9	68518
9	-12.8	64419
11	-11.7	60592
13	-10.6	57017
15	-9.4	53647
17	-8.3	50526
19	-7.2	47606
21	-6.1	44874
23	-5.0	42317
25	-3.9	39921
27	-2.8	37676
29	-1.7	35573
31	-0.6	33599
33	0.6	31732
35	1.7	29996


°F	°C	Ω		
37	2.8	28365		
39	3.9	26834		
41	5.0	25395		
43	6.1	24042		
45	7.2	22770		
47	8.3	21573		
49	9.4	20446		
51	10.6	19376		
53	11.7	18378		
55	12.8	17437		
57	13.9	16550		
59	15.0	15714		
61	16.1	14925		
63	17.2	14180		
65	18.3	13478		
67	19.4	12814		
69	20.6	12182		
71	21.7	11590		
73	22.8	11030		
75	23.9	10501		
77	25.0	10000		
79	26.1	9526		
81	27.2	9078		
83	28.3	8653		
85	29.4	8251		
87	30.6	7866		
89	31.7	7505		
91	32.8	7163		
93	33.9	6838		
95	35.0	6530		
97	36.1	6238		
99	37.2	5960		
101	38.3	5697		
103	39.4	5447		
105	40.6	5207		
107	41.7	4981		
109	42.8	4766		
111	43.9	4561		


°F	°C	Ω
113	45.0	4367
115	46.1	4182
117	47.2	4006
119	48.3	3838
121	49.4	3679
123	50.6	3525
125	51.7	3380
127	52.8	3242
129	53.9	3111
131	55.0	2985
133	56.1	2865
135	57.2	2751
137	58.3	2642
139	59.4	2538
141	60.6	2438
143	61.7	2343
145	62.8	2252
147	63.9	2165
149	65.0	2082
151	66.1	2003
153	67.2	1927
155	68.3	1855
157	69.4	1785
159	70.6	1718
161	71.7	1655
163	72.8	1594
165	73.9	1536
167	75.0	1480
169	76.1	1427
171	77.2	1375
173	78.3	1326
175	79.4	1279
177	80.6	1234
179	81.7	1190
181	82.8	1149
183	83.9	1109
185	85.0	1070
187	86.1	1034

# **Appendix B - Maxitrol Valve Adjustments**

The ES345D-L has a built in regulator for high fire. For M and MR series, adjust high fire with the upstream main regulator.

On DJ style burners, the top of the valve is piped into the burner box to provide a pressure to the top of the control valve regulator, extending its operating range and overcoming pressure differences due to the varying combustion blower speed. This is called Top Loading. When setting combustion on a top loaded valve, temporarily plug the small vent holes when the cover cap is removed to allow top loading to function during setup. Remove plug once setup is complete, and reinstall the cap cover.





# **Appendix C - Startup Checks**

- 1 Check and confirm all hardware connections
  - a. Terminal Plugs firmly attached.
  - b. Wiring connections.
- 2 Confirm ground bonding is correct and firmly fastened.
- 3 Confirm shielded grounds are correct.
- 4 Confirm internal Modbus wiring is correct (LmA and LmB).
- 5 Check all field electrical connections are intact and correct.

# **Appendix D - Service Issues**

# **CenCon Specific**

#### **READ AND SAVE FEATURES**

The majority of software settings in the CenCon program are specified at the time of the appliance design. Some settings can be field adjusted with a computer interface, including temperature and humidity setpoints, minimum damper position, combustion settings, etc.

The READ USER SETTINGS function references a configuration file located within the CenCon permanent memory and writes the data values from that table into the relevant parameters on the live system. Any changes to values on the system that were not previously saved will be overwritten.

The SAVE USER SETTINGS function writes data values from the live system to the permanent memory. This process will overwrite any previously saved data and will become the new configuration file when the controller is powered up.

#### **COMMUNICATION ALARM**

Check and confirm with correct communication wiring on the internal Modbus network wiring and connections.

#### **ERRATIC BEHAVIOR**

During shipping, it is possible for the terminal connectors that plug into the CenCon or expansion modules to come loose and separate from the controller. When performing the initial start-up of the appliance always confirm the terminals are firmly embedded into the controller. In addition, check the tightness of all wiring connections.

### HARD RESET BUTTON

Near the edge of the left side face of the CenCon face is a small button which is the hard reset button. If not correctly aligned with the cover plate, it is possible the button could be constantly depressed. In this circumstance the display will be blank, the 4 lights on the right side will not be lit, and the controller will be unresponsive to all commands.

### Miscellaneous

#### **COMBUSTION ANALYSIS**

Indirect heaters should be annually checked for quality of combustion.

### POOR PILOT SENSING

Check the condition of the pilot assembly. Check for damaged or dirty ceramics, and the condition of the gasket. Ensure the pilot air tube is free of debris and blockages. Note that on DJ's and DG's there is an orifice where the pilot gas line is connected to the pilot air tube. It must be free of dirt and burrs to operate properly. Pilot pressure is between 3 - 5"wc.

#### **REGULATOR RESPONSE**

On some indoor units the vent orifice fitting on the RV appliance regulator is to be vented to atmosphere. The field installed vent line must be sized in accordance with the requirements of the gas code in force.

Some DJ unit manifolds have RV appliance regulators with a vent-limiting orifice, usually a brass orifice marked '12A06'. Ensure that this tiny orifice is free of dirt or debris. A plugged orifice will impede regulators opening flow and cause improper air/fuel mixtures.

#### WATER AND ICE FROM COMBUSTION

Water is one of the major products of combustion. As the flue temperature drops, and the efficiency increases, the amount of water condensing to liquid will also increase. Extended chimneys can contribute to condensation problems. Increasing the excess air is a method of reducing the amount of water condensate. Increasing excess air by 1-2% will assist in keeping the flue gases drier.

### **MANIFOLD PRESSURE**


Manifold pressure settings that the unit was tested and clocked at in the factory are recorded on the unit rating plate. Any attempt to clock a unit in the field should be done with care. Corrections for density (altitude and station pressure), temperature, and the correction factor for the meter are often overlooked, thus leading to an incorrect conclusion.

### **CUSTOMER INSTALLED SENSORS**

If there is a temperature sensor to be installed in the discharge, that sensor must be mounted within  $\frac{1}{2}$  inch of the Engineered Air sensor. BMS (Building Management System) discharge air temperature sensors should never be used to reset the temperature of the heater. Only use space or room mounted sensors.

Humidity sensing should never sense discharge air. During normal operation the RH% will vary as the sensible and latent temperatures change due to heating and cooling. Only use return air or room sensing for humidity control.

### SPEED SENSOR - DJ



With a digital AC voltmeter, measure the AC volts present on terminals "YS to GS". When the combustion blower is running there should be 4 to 6 Vac present. If the AC voltage is not present, check the tachometer sensor to magnet gap. It should be 1/16 to 1/8 inch. If the gap is satisfactory, attempt to repair by flipping the magnet over, then flipping the tachometer sensor over, before replacing the tachometer sensor to correct the problem. Note: No part of the speed sensor's sensing element should be located over the end of blower motor shaft.

### **TOP LOADING**

Ensure the top loading tube from the modulating valve is located is not pointed directly UP. Ideally it enters from the bottom and is located at either side of the burner box and bent to a 90° angle pointed towards the heat exchanger. This location was chosen to obtain reasonably constant pressure readings not affected by air velocity.

### AIR BALANCING

Installation and air balancing is often done during warmer weather than that experienced in the cold of winter. If the air balance did not account for ambient temperature, the appliance could be having lower than expected temperature rise in cold weather conditions. As the fan is a constant volume device and as it is located before the heat exchanger, air will expand as it is heated. The amount of change could be up to a 20% increase in air volume from -30°F to +70°F.



# Appendix E - BACnet / Modbus

The CenCon supports BACnet MS/TP RS-485 and BACnet/IP. The Baud rate can be adjusted from 19200 to 38400 for MS/TP networks. For detailed information refer to the CenCon Communication Manual for Modbus and BACnet at <a href="https://www.engineeredair.com/manuals/">https://www.engineeredair.com/manuals/</a>.

# Wiring

The CenCon can be connected to either a BACnet® RS-485 network or a to a BACnet® Ethernet/IP network. The BACnet MS/TP RS-485, & BACnet/IP communication cables must conform to BACnet specifications.

#### **RS485**

The CenCon has a gray terminal strip that is used for all RS-485 communication connections. Terminals BnA and BnB have been designated and must be used to connect to the RS-485 BACnet network. The RS-485 communication cable to the CenCon should be a 24awg shielded twisted pair (STP) with a shunt capacitance of 16pF per foot and 100 ohm characteristic impedance.

### **Ethernet**

The CenCon is equipped with a standard RJ45 Ethernet port located on the top of the controller. The Ethernet port is designed to be incorporated with a BACnet® over IP network that is used to communicate with the building EMS.

# Appendix F - DJ/DG Fuel Curve Development

### Clocking notes:

- Correct values for Altitude.
- Ensure inlet pressure is correct at each stage.
- All clocked values should be within 5% of the calculated value.
- Offset values are set by 0.1Vdc increments. If results at low fire are not exact, and either too little or too much gas, use too much so as not to exceed maximum turn down.
- Where possible, use a small meter to improve clocking times at lower firing rates

Whenever possible at each stage, allow a few minutes for the heat exchanger temperature to stabilize before finalizing combustion values.



Ensure firing rates (and motor rpm, if used) increase as the combustion range increases from low to high fire.

For example, do not have the clocked Near Low Fire rate less than the Low Fire value. The pressure must be more than the Low Fire value.

- 1. High Fire. Adjust inlet regulator to achieve correct clocking, while adjusting Pac-Man (DJ) or DG Air Offset for clean burn.
- 2. Near High Fire. Multiply High Fire clocking by Ratio (X 1.1), and re-clock. Adjust gas and/or air offset values if required. Record new clocking value, manifold pressures, burn, and Air and Gas offsets.
- 3. Low Fire. Multiply High Fire clocking by Ratio, and re-clock.
  - a. Adjust bypass orifice and/or air offset if required on DJ. Record new values.
  - b. Adjust gas and/or air offset values if required on DG. Record new values.
- 4. Continue same process with Near Low Fire, Medium Fire 1, and Medium Fire 2.
- 5. Set to High Fire and confirm correct inlet pressure.
- 6. Set to Low Fire to confirm clean burn throughout range.
- 7. Finished combustion setup. Save values.
- 8. Shut down and restart heat to confirm good ignition.
- 9. Allow heating to run on automatic for a few minutes.

Example #1: high fire clocking is 10 seconds Example #2: high fire clocking is 30 seconds

			Calculated
Name	% Fire	Ratio	Example #1 Example #2
High Fire	100	1.0	10 30
Near High Fire	90	1.1	11 33
Medium Fire 2	55	1.8	18 54
Medium Fire 1	25	4.0	40 120
Near Low Fire	10	10.0	100 300
Low Fire - DJ	6.67	15.0	150 450
Low Fire - DG	5	20.0	200 600

# Combustion Record - DJ and Large SH/SHX

λ	
١,	•

High fire gas and air offsets should be set to zero. Use the PacMan to set air and the appliance regulator to set gas.

Serial and Tag#	Date	
Model #	Technician	
Job Name	Location	

Sequence	1	2	3	4	5	6
Name	High Fire	Near High Fire	Low Fire	Near Low Fire	Medium Fire 1	Medium Fire 2
% Fire	100	90	6.67	10	25	55
Man. Press.						
Oxygen - O <sub>2</sub>						
со						
RPM						
Air Offset	0					
Gas Offset	0		*			
Gas mA/Vdc						
		FA	CTORY CLOCK	ING		
Clocking						
Calculated						
Clock Ratio	1.0	1.1	15.0	10.0	4.0	1.8

<sup>\*</sup> Set to zero when using Maxitrol. Low fire is set on valve mechanical bypass. Only adjust offset if unable to achieve clocking with the bypass.

Setup Comments:		

# **Combustion Record - DG**

4	٥	
	Ĭ	\
•	•	•

High fire gas offset should be set to zero. Use the appliance regulator to set.

Serial and Tag#	Date	
Model #	Technician	
Job Name	Location	

Sequence	1	2	3	4	5	6
Name	High Fire	Near High Fire	Low Fire	Near Low Fire	Medium Fire 1	Medium Fire 2
% Fire	100	90	5	10	25	55
Man. Press.						
Oxygen - O <sub>2</sub>						
со						
Air Offset						
Air Vdc						
Gas Offset	0					
Gas Vdc	10					
FACTORY CLOCKING						
Clocking						
Calculated						
Clock Ratio	1.0	1.1	20.0	10.0	4.0	1.8

Setup Comments:		

## **Combustion Record - HE**

<b>/!</b> \	

High fire gas offset should be set to zero. Use the appliance regulator to set.

Serial and Tag#	Date	
Model #	Technician	
Job Name	Location	

- 1. Set profile pressure drop to 0.7"wc by blocking the discharge. If unable, then <u>evenly</u> block off inlet.
- 2. High Fire. Adjust inlet regulator to achieve correct clocking.
- 3. Observe high fire flame for burn quality.
- 4. Reduce to low fire and set flame length. Clocking not required. Note values below on testbay spreadsheet.
- 5. Finished combustion setup. Save values.
- 6. Shut down and restart heat to confirm good ignition.
- 7. Allow heating to run on automatic for a few minutes.

Sequence	1	2
Name	High Fire	Low Fire
Manifold		
Pressure		
Gas Offset	0	*
Gas mA/Vdc		
FA	CTORY CLOCKI	NG
Clocking		
Calculated		

<sup>\*</sup> Set to zero when using Maxitrol. Low fire is set on valve mechanical bypass.

Setup Comments:		
		_

# **Combustion Record - Small SH/SHX**

This style equipment uses hot surface ignition with constant combustion air. Combustion setup is for high and low fire only.

^	
<b>/</b> !	\

High fire gas and air offsets should be set to zero. Use the PacMan to set air and the appliance regulator to set gas.

Serial and Tag#	Date	
Model #	Technician	
Job Name	Location	

-				
Sequence	1	2		
Name	High Fire	Low Fire		
% Fire	100	33.3		
Man. Press.				
Oxygen - O <sub>2</sub>				
СО				
Gas mA				
Factory Clocking				
Clocking				
Calculated				
Clock Ratio	1.0	3.0		

Setup Comments:			